

DMX Chart

5-Channel Mode (DMX/ART-NET/sACN) STROBE	
CHANNEL	FUNCTION
1	DIMMER
2	STROBE CW + RGB
3	MACRO RGB (1-17)
4	MACRO CW (1-17)
5	Macro SPEED (SLOW->FAST)

10-Channel Mode (DMX/ART-NET/sACN)	
CHANNEL	FUNCTION
1	DIMMER
2	STROBE (WHITE)
3	STROBE (RGB)
4	RED-ALL Dimmer
5	GREEN-ALL Dimmer
6	BLUE-ALL Dimmer
7	CW-ALL Dimmer
8	MACRO RGB (1-17)
9	MACRO CW (1-17)
10	MACRO SPEED (SLOW->FAST)

36-Channel Mode (DMX/ART-NET/sACN/DMX+A/DMX+sACN)	
CHANNEL	FUNCTION
1	DIMMER
2	STROBE (WHITE)
3	STROBE (RGB)
4	MACRO RGB (1-17)
5	MACRO CW (1-17)
6	MACRO SPEED (SLOW->FAST)
7	CW Segment 1
8	CW Segment 2
9	CW Segment 3
.....
10	CW Segment 30

DMX Chart

126 -Channel Mode (DMX/ART-NET/sACN/DMX+A/DMX+sACN)	
CHANNEL	FUNCTION
1	DIMMER
2	STROBE (WHITE)
3	STROBE (RGB)
4	MACRO RGB (1-17)
5	MACRO CW (1-17)
6	MACRO SPEED(SLOW->FAST)
7	RED Segment 1
8	GREEN Segment 1
9	BLUE Segment 1
10	CW Segment 1
11	RED Segment 2
12	GREEN Segment 2
13	BLUE Segment 2
14	CW Segment 2
15	RED Segment 3
16	GREEN Segment 3
17	BLUE Segment 3
18	CW Segment 3
.....
123	RED Segment 30
124	GREEN Segment 30
125	BLUE Segment 30
126	CW Segment 30

DMX Chart

390 -Channel Mode (DMX/ART-NET/sACN/DMX+A/DMX+sACN)	
CHANNEL	FUNCTION
1	CW segment 1
2	CW segment 2
3	CW segment 3
4	CW segment 4
.....
30	CW segment 30
31	RED LED 1
32	GREEN LED 1
33	BLUE LED 1
34	RED LED 2
35	GREEN LED 2
36	BLUE LED 2
.....
388	RED LED 120
389	GREEN LED 120
390	BLUE LED120