

# Wireless DMX Transceiver LC-512 Series User Manual - Version 2.0

Thank you for choosing LTH PROFESSIONAL LC-512 Series Wireless DMX Transceiver. LTH PROFESSIONAL LC-512 Series is unique in its use of advance radio technologies that are also used in military communication and mobile phones. Its user-friendly operation that simplifies all the complex communication protocols makes it possible for the users to plug and play.

LTH PROFESSIONAL LC-512 Series uses 2.4GHz global open ISM band with license-free use. The Gaussian Frequency Shift Keying (GFSK) modulation, Frequency Hopping Spread Spectrum (FHSS) with 79 channels interference-free operation.

LTH PROFESSIONAL LC-512 Series is continually considered as a reliable wireless DMX product for lighting installations over large distances and in any environment.

There are no upgrading troubles. Because ours is now compatible with the world's leading wireless communication protocols like the Sweden's protocol or the GZ protocols.

For complete instructions and product features, please read this manual or visit our website at www.lth-gmbh.de

#### Content

- SAFETY INFORMATION
- **STATEMENT**
- 1 INTRODUCTION
  - FEATURES
  - SPECIFICATIONS
  - PACKING LIST
  - INTERFACE
- **OPERATING GUIDE** 
  - OPERATING MODE
  - DESCRIPTION OF STATUS INDICATOR
  - SELECT WIRELESS GROUP
  - RESTORE FACTORY SETTINGS
  - CONNECTION AND DELETE CONNECTION
- **APPLICATIONS** 
  - ONE TRANSMITTER TO ONE RECEIVER.
  - ONE TRANSMITTER TO MANY RECEIVERS
  - PARALLEL TRANSMISSION
  - REPEATER OR AMPLIFIER
- **MAINTENANCE**



#### Safety Information

Please keep the product far away from the heat. It should be away from the heater, radiator or any other heat source. Heat will damage and break the product, even worse it may start a fire.

Please shutdown the product where there are slogans like "Explosion" Zone", "May Burst Area" and "Turn off the wireless transceiver" or somewhere such as Hospital, Gas Station and Airport.

It may bring trouble for some medical electronic equipment like hearingaid and cardiac pacemaker and so on. Please follow the warning notes and safety instructions.

Please use the attached power adapter. It might damage the device if using unapproved power adapter.

# 1 Introduction

#### 1.1 Features

LTH PROFESSIONAL LC-512 Series is unique in its use of advance radio technologies that are also used in military communication and mobile phones. Its user-friendly operation that simplifies all the complex communication protocols makes it possible for the users to plug and play.

- 2.4GHz ISM Band, license-free worldwide
- FHSS with 79 Channels, interference-free operation
- 32-bit ARM processor, DMA transfer without delay
- Standard DMX512 3-pin XLR, 5-pin XLR, transceiver
- Built-in Wireless Solution compatibility mode
- Group Mode, easy plug-and-play operation; Pairing Mode, supports more transmitter universes

#### 1.2 Specifications

- Band: 2.402GHz 2.480GHz, ISM, 79 channels
- Spread spectrum: FHSS, 1100 hops / sec
- Modulation: GFSK
- Maximum Transmit Power: 23dBm
- Receiver Sensitivity: -94dBm
- Power: DC 5V ± 10% Size: 212 x 18 x 18 mm



# 1.3 Packing List

Delivery includes:

- 1) Wireless DMX Transceiver 1pcs
- 2) Power Adapter 1pcs
- 3) User Manual 1pcs

#### 1.4 Interface

- 1, DMX512 3-pin or 5-pin male or female XLR
- 2, External power supply input
- 3. Status indicator
- 4. Button
- 5, Antenna

# 2 Operating Guide

#### 2.1 Operating mode

Wireless transceiver has two operating modes: set-up mode and use mode

1, Set-up mode: Press and hold the button before you power up. When you see status indicator turns into the white light, release the button to enter the Set-up mode. In this mode you can select different transmission protocols. Each time you press the button, you would see the status indicator changes in follow order: red, green, blue and yellow. In the Set-up mode, different colors mean different communication protocols which are listed on the following table. Choose one of the protocols and press and hold the button (> 1S), when you see the white light, release it to enter the use mode.

Note: The wireless transceiver will remember the chosen protocol even after you disconnecting the power supply. There is no need for repeated setting.

## Color Protocol

Red WI-DMX

Green W-DMX Receive Blue W-DMX G3 Transmit

Yellow **GZ Protocol** 

Purple W-DMX G4 Transmit



# 2. Use mode:

- a) Powered up and enter the use mode;
- b) If it is in set up mode, press and hold the button (> 1S) until you see the white light, then release it to enter the use mode.

# 2.2 Description of Status

Protocol	Action	Status Description	
	Red, Green, Blue,		
WIDMX	D. LL. Tallo	6 / 7 Different Wireless	
	Yellow, Cyan,	Commo	
or	Purple (, White)	Groups	
GZ	Turple (, Time)		
	Red Flashing	Transmitting DMX	
Protocol	Green Flashing	Receiving DMX Signal	
	e terresia de la companio del companio de la companio del companio de la companio del la companio de la compan		
W DMV	White	Connection is not	
W-DMX Receive		Established	
	Red	Deleting Connection	



Red(Fast-Flash)  Green(Fast-Flash)	Red(Fast-Flash)	Connection is Lost
	Connecting to	
	Green(Fast-Flash)	Transmitter
3	3	Connected, Without
	Green(Slow-Flash)	DMX Signal
	Green	Connected, Receiving
		DMX Signal
W-DMX Transmit		Deleting all Receivers'
	Red	Connection
	Blue(Fast-Flash)	Connecting with the
		Receiver(s)
	Blue(Slow-Flash)	No DMX Signal Input
	Blue	Transmitting DMX



#### Note:

1. Flashing: > 20ms ON + <180ms OFF (Depending on the refresh rate of the DMX signal)

2. Fast-Flash: 100ms ON + 100ms OFF 3. Slow-Flash: 900ms ON + 100ms OFF

# 2.3 Select Wireless Group

Each time you press the button, the status indicator will change different colors. In this case different colors mean different groups. Only when the indicators of the transmitter and receiver show the same color they can communicate with each other.

When the transmitter connects to the controller, the status indicator of the transmitter would flash red. If the receiver gets the DMX signal, the indicator would flash green.

NOTE: The first time when you press the button, it will not change the color but show you the group that you are in. If you press it again it will switch to other group.

# W-DMX mode supports 6 groups (FHSS, 1100 hops / sec)

1: RED	Red
2: GREEN	Green
3: BLUE	Blue
4: RED + GREED	Yellow
5: GREEN + BLUE	Cyan
6: RED + BLUE	Purple

# GZ protocol supports 7 groups (Frequency Agile)

1: RED	Red
2: GREEN	Green
3: RED + GREED	Yellow
4: BLUE	Blue
5: RED + BLUE	Purple
6: GREEN + BLUE	Cyan
7: RED+GREED+BLUE	White



#### 2.4 Restore factory settings

By pressing and holding the button (> 1S), When see the BLUE flashing, Then release the button, the devices would flash "RED-GREEN-BLUE" quickly, and then turns red. It indicates that the device has restored to factory settings successfully. The default group is red.

#### 2.5 Connection and Delete

#### Connection

In the W-DMX G3 or G4 Transmit Mode, by pressing the button, the transmitter can be connected to all powered but not connected receivers within the coverage area; Press and hold (> 3S) the transmitter's button until the indicator turns red. The device will disconnect with all receivers within the coverage range.

In the W-DMX Receive Mode, Press and hold (> 3S) the receiver's button until the indicator turns white. The device would disconnect with the transmitter.

Note: Receiver could only be connected to the new transmitter after the old connection is deleted.

# 3 Applications

#### 3.1 One transmitter to one receiver

Controller inputs DMX signal onto a wireless transmitter, and the latter would send DMX signal via Radio to the receiver with the same group or to the receiver connected.

## 3.2 One transmitter to many receivers

Controller inputs DMX signal onto a wireless transmitter, and the latter would send DMX signal via Radio to the receivers with the same group or the other receiver connected.



#### 3.3 Parallel Transmission

Many sets of radio transmitters can be operated simultaneously, without mutual interference.

# 3.4 Repeater or Amplifier

If directly connect a receiver to a transmitter (both the receiver and transmitter work in different groups or in different sets), it would become a repeater or amplifier. In this way, the working distance increases.

# 4 Maintenance

Please storage and use the device within required temperature. Device may damage if the temperature is too high or too low.

The device is not water-proof. Please keep the item and its accessories dry. Please do not use it in bathroom or other place with high humidity. Do not let water or other liquid seep into the device, or it may be damaged.

Do not place and use the device in dusty place.

Please use a soft, slightly moist cloth to clean the outer case. Never use alcohol, acetone or other similar solvent to clean it.

Please do not attempt to take apart the device and repair it by yourself. If the device is detected, please contact with the dealer as soon as possible